



## OUR RECOMMENDATIONS

# PERFECT INSTALLATION HEIGHTS

Everyone is different, which is why everyone will have a different idea about what the perfect installation height is. If nothing is said to the contrary, plumbers will install bathroom elements at the heights stipulated in the standard.

- 1 TOILET**  
 15" (standard seat height)  
 Geberit recommendation: 16"
- 2 WASHBASIN**  
 Height top edge washbasin ceramic: 33.5" – 35.5"
- 3 MIRROR OR MIRROR CABINET**  
 Height bottom edge: 39" – 49"  
 Height top edge: 79" – 87"  
 Height eye area: The center of the mirror surface.  
 This depends whether people with a lower eye level also want to comfortably use the mirror.
- 4 CLOTHES HOOK**  
 Between 3.5 and 4 ft