



Geberit Cover Plates, Sigma for Use with Flush Buttons

115.764 115.766 115.768 Actuator Dimensions: 9.7" x 6.5" (24.6 cm x 16.4 cm)




Item			Model No.	Description	List Price \$
2	2	2	241.093.00.1	Fastening for cover plate UP300 set-2	22.00
3	3	3	241.873.00.1	Conversion set for tool-free installation	37.00
3.1	3.1	3.1	241.874.00.1	Actuator rod set mount w/o tool (From 2008)	15.00
3.2	3.2	3.2	241.876.00.1	Mounting frame tool-free (From 2008)	17.00
4	4	4	241.877.00.1	Screw for Twist, Tango, Mambo set-2. For tool-free mounting frame.	56.00
5	5	5	240.938.00.1	Extension set for C/C UP200/UP300	28.00

< 2008



> 2008



The information contained in this document is subject to change without notice.